

DOC REF NO.	RD/PCU/10K/120V/R.01
PRODUCT FG CODE	SPD-SV-103-120-01
Product Specification Range of Solar PCU	
Model Name	SAVER 10000
MAINS INPUT MODE	
Mains AC low cut UPS mode	175VAC ± 10VAC
Mains AC low cut recovery UPS mode	185VAC ± 10VAC
Mains AC high cut UPS mode	265VAC ± 10VAC
Mains AC high cut recovery UPS mode	255VAC ± 10VAC
Mains AC low cut WUPS mode	90VAC ± 10VAC
Mains AC low cut recovery W.UPS mode	110VAC ± 10VAC
Mains AC high cut WUPS mode	295VAC ± 10VAC
Mains AC high cut recovery W.UPS mode	285VAC ± 10VAC
Input Frequency Range	40Hz to 60Hz
Voltage Output in Mains Mode	Same as input
Frequency Output in Mains Mode	Same as input
BATTERY	
Battery Type	LA / Tubular / SMF
DC input voltage	120V
Battery Quantity 12V 100Ah to 220Ah	10
Float charging voltage	137V±0.4V
Bulk absorption Voltage	148V±0.4V
Boost charging voltage for LA Battery	139.5V±0.5V
Boost charging voltage for Tubular and SMF Battery	144.5V±0.5V
Battery deep Discharge Recovery	Yes (Independent Charger to Recover Deep Discharge Battery)
Charging Current at Grid priority/Battery priority	13A ± 3A
BACKUP MODE	
Output voltage	220VAC±10%
Output frequency	50Hz ± 0.2 Hz
Output waveform	Pure Sine Wave ≤ 5% THD
No Load current	<1.8A
Capacity	10KVA
Discharging current @ full load	66A ± 2A
Low Battery Warning	108±0.5V
Low Battery Cut	104V±0.5V
Change over time UPS mode	< 4msec
Change over time WUPS mode	< 25msec
PROTECTIONS	
Overload in backup mode	Yes provided, system will indicate on display at 101% load
Short Circuit in Backup Mode	System will shutdown after 3 - retries in case of output short circuit
Short Circuit in Mains Mode	Mains MCB will trip
Back feed	System will shutdown in case of back feed and there is no retry
Over temperature	Yes provided, if heat sink temperature goes above 100°C System will shut down
Reverse Battery	Battery MCB will trip
Phase to Phase protection in mains mode	Yes provided by electronic
SOLAR CHARGE CONTROLLER	
Solar Charge Controller type	PWM type
Max Panel wattage can be connected	8000W
Max PV current	50A
Reverse PV protection	Yes provided
Reverse current flow to PV	Yes provided
Sharing of current when PV and Grid Both are available	If PV power is not sufficient enough to charge the battery, system will start sharing battery charging from PV and grid.
Option for Grid and Battery priority	Yes, provided, user can set priority for Battery or Grid. Hence user can set system in electricity bill saving.
DISPLAY AND ALARMS	
LCD Initial Display	Welcome, SMARTEN Website Address, System Capacity, Charging Till 90VAC and Deep Discharge Battery, System Setting, UPS / WUPS mode, I/P range 90-295VAC / 170-265VAC, Battery Type Selected LA / SMF / Tubular,
LCD Status Display	Mains ON, Input Voltage, Input Frequency, Battery Voltage, Battery Charging, Battery Charged, Charging Current, Backup Mode, UPS ON, UPS OFF, Battery Voltage, Load %, Output Voltage, Output Frequency,
Buzzer	Audible beep for Overload, Short Circuit, Back feed, Low Battery, Over Temperature, Mains Fuse blown / MCB Trip
SAFETY	
HV Test Input to Earth	Leakage current <5mA when 1.5kV applied for 1 min
HV Test Output to Earth	Leakage current <5mA when 1.5kV applied for 1 min
IR Test Input to Earth	>5MΩ between @ 500VDC
IR Test Output to Earth	>5MΩ between @ 500VDC
Earth Leakage current in Mains mode	< 2.5mA
Earth Leakage current in Backup mode	< 2.5mA
WEIGHT AND DIMENSIONS	
Dimensions in mm	550x410x650